

NOTE:
FOR NON-NAILABLE
SUBSTRATES, FASTENERS
MUST BE USED ONLY AT
STUD FRAMEWORK
LOCATIONS.

MOISTURE BARRIER
APPLIED TO
FACE OF
SUBSTRATE
(BY OTHERS)

WORKING POINT
IS FACE OF
TYVEKO / SUBSTRATE

WEEP BAFFLE

ATTACHMENT
EXTRUSIONS

NAILABLE SUBSTRATE
(BY OTHERS)

FASTENER
(BY OTHERS)

ENVELOPE 20000

1

SYSTEM ISOMETRIC

